





Blade automatically locked.



Push button to release auto-lock break when 1) pulling out and 2) retracting blade.

Measurement aid



Use reference point as measurement aid.

6





ம் SEND




- 1 Measuring reference point front
- 2 Auto-lock brake release button
 - ON | OFF | SEND measuring data
- 4 Switch mm, cm I set measuring reference point
- 5 Digital display
 - USB charging port
- 7 Measuring reference point rear









SOLA-Messwerkzeuge GmbH Unteres Tobel 25, A-6840 Götzis Tel: +43 (0)5523 53380-0 sola@sola.at. www.sola.at



Please find the operating instructions on sola.at

Download free SOLA Measures app to connect CITO to your smartphone via Bluetooth.













R373290